

# Variable Reluctance Speed Sensor for Use in Explosive Atmospheres Ex ia and Ex d

## EX34H35

**GREEN LINE**  
INDUSTRIAL SPEED SENSORS

### Product ID

Type #	Product #	Drawing #
EX34H35	385Z-05638	114.650 Rev.0

### General

**Function** The EX34H35 series variable reluctance (VR) speed sensors consist of an iron core, an inductive coil, and a permanent magnet. A ferrous pole wheel passing the sensor face changes the magnetic field strength, resulting in an AC voltage being induced in the coil. The frequency of the output signal is proportional to the speed of the moving target. The amplitude of the signal depends on speed, air gap, geometry of target, magnetic properties of target material, and the electrical load. VR sensors, also known as passive or electromagnetic sensors, do not require an external supply.

**Usage in an explosion risk environment** Certification pending. Details will follow after finished certification.


**Marking** II 1 G EEx ia IIC T6-T1 (pending)

### Technical data

- Coil properties**
- Inductance @ 1 kHz: 70 mH ± 10%
  - Resistance of entire sensor: 2950 Ohm ± 10% (coil without energy protecting devices: 250 Ohm)
  - Magnet polarity: south pole towards front face
  - Pole piece: diameter 2.7 mm

**Polarity** Upon approach of ferrous metal, the signal pin is positive with respect to GND.

**Signal output** The signal frequency is proportional to the target speed. The signal amplitude shown in the figure is valid for a load of 100 kOhm, and is affected by air gap, target geometry and material. It is also proportional to the linear speed of the teeth.



**Frequency range** Up to 20 kHz, lower limit depending on application

**Housing** 3/4"-20 UNEF-2A, tightening torque: max. 40 Nm

**Connection** Cable for ex applications, properties **tbd**

**Protection** **tbd**


**Insulation** Housing and electronics galvanically isolated (Test: 500 V, 50 Hz for 1 minute)

**Pole wheel** Prerequisite: Toothed wheel of a ferrous material (e.g. Steel 1.0036).  
Optimal performance with

	<ul style="list-style-type: none"> <li>• Involute gear</li> <li>• Tooth width &gt; 10 mm</li> <li>• Side offset &lt; 0.2 mm</li> <li>• Eccentricity &lt; 0.2 mm</li> </ul>
Air gap between sensor and pole wheel	Depending on lowest circumferential speed which has to be detected, on trigger level and ex safety parameters. See figure and ex information.
Electromagnetic compatibility (EMC)	Please contact Jaquet for further details.
Vibration & shock immunity	Jaquet Greenline sensors are approved for rough environments. Please contact Jaquet for further details.
Operating temperature	-40°C...125°C


### Further Information

Safety	All mechanical installations must be carried out by an expert. General safety requirements have to be met.
Installation	<p>The sensor has to be aligned to the pole wheel according to the sensor drawing independent of its rotational orientation. Deviations in positioning may affect the performance and decrease the noise immunity of the sensor. During installation, the smallest possible pole wheel to sensor gap should be set. The gap should however be set to prevent the face of the sensor ever touching the pole wheel. A sensor should be mounted with the middle of the face side over the middle of the pole wheel. Dependent upon the wheel width, a certain degree of axial movement is permissible. However, the middle of the sensor must be at minimum in a distance of 3 mm from the edge of the pole wheel under all operating conditions.</p> <p>A solid and vibration free mounting of the sensor is important. Eventual sensor vibration relative to the pole wheel can induce additional output pulses. The sensors are insensitive to oil, grease etc. and can be installed in arduous conditions.</p>
Maintenance	Product cannot be repaired.
Transport	Product must be handled with care to prevent damage of the front face.
Storage	Product must be stored in dry conditions. The storage temperature corresponds to the operation temperature.
Disposal	Product must be disposed of properly, it must not be disposed as domestic waste.



part no.	typ	A	B
385Z-05637	EX34H	48	88
385Z-05638	EX34H35	89	129

connecting diagram:



**EX-CERTIFIED PRODUCT**  
MUST BE APPROVED BY THE AUTHORIZED JAQUET  
EX-REPRESENTATIVE

FOR TECHNICAL SPECIFICATIONS SEE OPERATING INSTRUCTION

dimensions in mm						
part no.	material / remarks			application		
-	-	-/-	-	nominal size range		
-	-	-/-	-	allowed tolerance		
-	-	-/-	-	replacement for		
-	-	-/-	-	first angle projection	drawn	19.03.2007
-	-	-/-	-		approved	31.5.07
rev.	ecn.	date/signature	change description	format	drawing no.	rev.
<p>Thannerstrasse 15 CH-4009 Basel www.jaquet.com</p>				scale	1:1	
				format	A4	drawing no.
				file name	114650.dft	

part name  
**speed sensor Greenline EX34H**